



**VERITEK**

## POWER METERS



**1 PHASE METER**  
**VIPS 999P (96x48)**

### TE T E T T E

Type : **1 PHASE METER**

Accuracy : Class 0.5 for V & A; 0.1%  
of FS for Hz

Accuracy Test :  
**1Ø Meter**

VOLTAGE		CURRENT		FREQUENCY
10%	100%	10%	100%	100%
+/-0.5%	+/-0.5%	+/-0.5%	+/-0.5%	+/-0.1%
OK	OK	OK	OK	OK

Power Factor		Watts		kVA
10%	100%	10%	100%	100%
+/-0.5%	+/-0.5%	+/-0.5%	+/-0.5%	+/-0.1%
OK	OK	OK	OK	OK

#### Note :

A) For Digital Readouts the error is Computed in Counts.

- Class 1.0 =  $\pm 1\%$  of Full Scale  $\pm 1$  Count
- Class 0.5 =  $\pm 0.5\%$  of Full Scale  $\pm 1$  Count

Tested By :

Date :




### VERITEK ENGINEERING PVT. LTD.

Plot No. 222, EL-Electronic Zone, MIDC, TTC Industrial Area,  
Mahape, Navi Mumbai - 400701, India  
Tel. : +91 86557 47987


Email : sales@veritekindia.com | Web : www.veritekindia.com

### E E


**VIPS 999P (96x48)**




Front View



Tolerance:  $92^{+2}_{-0} \times 44^{+0}_{-0.6}$   
Panel Cutout






Side View



### T G GE E T

**VIPS 999P (96x48)**



- 1) Remove the mounting clamps
- 2) Gently slide the Meter through the cut-out.
- 3) Put the mounting clamps back in the Meter.

### E T E

- (1) State of Art Micro controller Based Design
- (2) 1 Line 4 Digit Ultra Bright LED Display
- (3) Site Programmable PT ratio (Primary & Secondary)
- (4) Site Programmable CT ratio (Primary & Secondary)
- (5) True RMS Measurement
- (6) Password Protection
- (7) Harmonics THDV & THDI
- (8) Auto Ranging
- (9) Universal Aux. Supply

### P ETE


#### 1Ø Meter - VIPS 999 & VIPS 999P

Volts, Amps, Hz, PF, Active Power, Reactive Power, Apparent Power, Energy, THDV, THDI, Load Hours

### E T ET

#### Electrical Wiring / Connection Diagram

1 Phase Meter (96x48) - VIPS 999P



\*\* Connect Fuse = 0.25 A



### PE T

- Input** : 1Ø Meter - 1 Phase 2 Wire  
Range 0-300 V
- : 3Ø Meter - 3 Phase 4 Wire  
1 Phase 2 Wire  
Range 0-500 V
- Amps** : 0.015 to 6.00 Amp  
Direct 60 ampere optional
- Burden** : 3VA Max. for Aux. Supply, 0.2VA for  
Voltage & Current input
- Aux. Supply** : 90 - 270 VAC / DC, 50/60 Hz
- Display** : 1 Line x 4 Digit  
{ 0.56 Inches 7 Segment LED Display }
- Computation** : True RMS
- Frequency** : 45 Hz - 65 Hz
- Ambient** : -10 to 55°C
- Storage** : -20 to 75°C
- Humidity** : < 95% Non-Condensing
- Weight** : 280 gms
- Dimesions** : 96 x 96 x 46 mm (L x W x D)  
96 x 48 x 56 mm (L x W x D)
- Panel Cutout** :  $(90^{+2}_{-0})$ mm x  $(90^{+2}_{-0})$ mm  
 $(90^{+2}_{-0})$ mm x  $(44^{+2}_{-0.6})$ mm
- Mounting** : Flush Mounting with Side Clamps.

### E E E T GE

- Volts** : 0 - 500VAC L-L
- Amp** : 0.015A - 6.00Amp AC
- Display Update** : 1 Sec
- Hz** : 45 to 65 Hz
- Resolution** : 0.1 for Energy, auto ranging for  
other parameter.
- Accuracy** :  $\pm 0.5\%$  of full scale for voltage,  
current, power, power factor.
- Frequency** :  $\pm 0.1\%$  for Hz
- Energy** : class 1.0 Active / Apparen  
class 1.0 Reactive

## E

In this mode the display shows parameter of the selected page one after another.  
The parameter of next / previous page can be viewed by pressing  or  keys.

## T



## E

In this mode the display shows parameter of page 1 then scroll to page 2 and so on.












## P Y EE E E

This mode can be activated by pressing  key during normal meter operation.

When this key is pressed the display will remain on the parameter it is currently displaying.

In this mode  key can be pressed to see the other parameters of this page only, but to scroll to next page parameters first you have to come out of freeze mode. Pressing  key once again will bring the meter out of freeze mode.




































































## P YP GE

Page	Symbol	Parameters
1	V L-N 	Voltage (L-N)
2	A 	Amps
3	Hz 	Frequency
4	W 	Watts (Active Power)
5	Var 	Var (Reactive Power)
6	VA 	VA (Apparent Power)
7	PF 	Power Factor
8	AE 	Active Energy
9	u thd 	Harmonics - Voltage -THDV
10	i thd 	Harmonics - Current -THDI
11	t 	Load Hour

## P

## G

## G

USr		PROG	Press Programming
PRSS			Set 2000 (Factory Set Password 2862)
0000			
Rddr		PROG	Unit Address
PtPr			PT Primary
PtSc			PT Secondary
CtPr			CT Primary
CtSc			CT Secondary
CLrE			Clear Energy
nPRs			New Password
Rddr		PROG	To enter into address
001			To change value of address (Default value 001)
001		PROG	To Save
PtPr		PROG	To enter into PT Primary
0001			To change value of PT Primary (Default value 0001)
0001		PROG	To Save
PtSc		PROG	To enter into PT Secondary
0001			To change value of PT Secondary (Default value 0001)
0001		PROG	To Save
CtPr		PROG	To enter into CT Primary
0001			To change value of CT Primary (Default value 0001)
0001		PROG	To Save
CtSc		PROG	To enter into CT Secondary
0001			To change value of CT Secondary (Default value 0001)
0001		PROG	To Save
CLrE	CLr	ArE	 To enter into Clear Energy
	EnEr	You	 To not Clear Energy
	94 P	SurE	
nPRs		PROG	To enter into Change Password
2000			To edit new password
2000		PROG	To Save
bAud		PROG	To enter into Baud Rate
9600			To set baud rate (1200, 2400, 4800, 9600)
9600		PROG	To Save
PAR		PROG	To enter into Parity
EnEn			To set parity (Even, Odd, None)
EnEn		PROG	To Save
CLrE	CLr	ArE	 To enter into Clear Load Hour Timer
	Hour	You	 To not Clear Load Hour Timer
	t, P	SurE	
ScrL		PROG	To enter into select Auto / Manual Scroll
d, 5			To Disable / Enable Scrolling
d, 5		PROG	To Save
dYrO		PROG	To enter into select Display Rows
4			
4		PROG	To Save
uSPd		PROG	To enter into select next Parameter Update Speed
AuO			To set speed (average, slow, very slow, very fast, fast)
AuO		PROG	To Save
		PROG	To come out of program mode

## T

## ETYP E T

All safety related conditions, symbols and instructions that appear in this operating manual or on the equipment must be strictly followed to ensure the safety of the operating personnel as well as the instrument.

If the equipment is not used in a manner specified by the manufacturer it might impair the protection provided by the equipment.

If there is physical damage to the unit then do not use it.

Read complete instruction prior to installation and operation of the unit.

## GG E E

## T

- 1) To Prevent the risk of electric shock power supply to the equipment must be kept OFF while doing the wiring arrangement.
- 2) Wiring shall be done strictly according to the terminal layout with shortest connection. Confirm that all connection are correct.

## T



- 1) To ensure the safe operation of unit, check the wiring and connections.